

Снегоочистители POWER PUSHER TE

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

POWER PUSHERTM TE



STEEL
TRIP-EDGE
PUSHER



FEATURES & SPECIFICATIONS

STEEL TRIP-EDGE

Designed to deliver cleaner scrapes, the POWER PUSHER TE uses a steel trip-edge. Built to handle heavy-duty loads and stresses, the steel trip-edge uses four extension springs along with two outer double ribs at the trip springs. The framing and 63-degree angle of attack is based on years of field testing and development.

STRUCTURAL SUPPORT

Six vertical support ribs provide the structural integrity needed to prevent twisting and maximize bucket impact strength, giving you the confidence to push more snow into higher stacks.

SIDE SUPPORT POSTS

Side support posts provide protection to the wings against bending from hitting curbs or other accidental impact.

HIGH-QUALITY PAINT

High-quality industrial paint is salt-resistant and UV-resistant to protect against corrosion and other environmental effects.

Additional Features: 10-Gauge Steel Moldboard, Bolt-On Side Plates Adjustment, Blade Attachment, Brush Cover

ACCESSORIES



BACK DRAG EDGES

Top mounted, rubber back drag edge allows operators to pull snow away from loading docks, doors and other tight spaces.



HIGH-WEAR SHOES

High-wear shoes provide increased service life for extreme use applications.

See Page 30 for full list of accessories.

MACHINE FLEXIBILITY

Interchangeable attachment plates allow the same pusher to work with a wheel loader/backhoe, skid-steer, or tractor simply by having the correct attachments.



Wheel Loader/
Backhoe

Skid-Steer

Tractor

MODEL:	8' PUSHER	10' PUSHER
Box Width	8'	10'
Blade Height	32.5"	32.5"
Weight	1,012 lb	1,140 lb

POWER PUSHER^(TM) TE Specifications

Dimensions

<i>Imperial</i>	<i>8' Power Pusher TE</i>	<i>10' Power Pusher TE</i>
Blade Width	8'	10'
Blade Height	32.5"	32.5"
Blade Gauge	10	10
Approx. Weight*	1,012 lb	1,140 lb

<i>Metric</i>	<i>8' Power Pusher TE</i>	<i>10' Power Pusher TE</i>
Blade Width	243.8 cm	304.8 cm
Blade Height	82.6 cm	82.6 cm
Blade Gauge	10	10
Approx. Weight*	459.0 kg	517.1 kg

Operational

<i>Imperial</i>	<i>8' Power Pusher TE</i>	<i>10' Power Pusher TE</i>
Snow Capacity	6.4 cu yd	8 cu yd
Horsepower - Skid-Steer*	45+ hp	60+ hp
Horsepower - Wheel Loader*	60+ hp	60+ hp
Horsepower - Tractor*	40+ hp	50+ hp

<i>Metric</i>	<i>8' Power Pusher TE</i>	<i>10' Power Pusher TE</i>
Snow Capacity	4.89 cu m	6.1 cu m
Horsepower - Skid-Steer*	45+ hp	60+ hp
Horsepower - Wheel Loader*	60+ hp	60+ hp
Horsepower - Tractor*	40+ hp	50+ hp

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93